




SUBARU

FORESTER FRONT GRILLE
FORESTER FRONT GITTER
FORESTER GRILLE AVANT
FORESTER GRATA ANTERIORE
FORESTER LA VERJA DELANTERA


INSTALLATION INSTRUCTION
EINBAUANLEITUNG
INSTRUCTIONS DE L'INSTALLATION
ISTRUZIONI USO
INSTRUCCIONES PARA LA INSTALACION
(2008, January)

PART.No




J1010SC100##





①



②









SUBARU

FORESTER FRONT GRILLE
 FORESTER FRONT GITTER
 FORESTER GRILLE AVANT
 FORESTER GRATA ANTERIORE
 FORESTER LA VERJA DELANTERA

Disassembling and reassembling procedure
 Anleitung für Montierung und Demontierung
 Procédure de montage et de démontage
 Istruzioni montaggio e smontaggio
 Instrucciones para montaje y desmontaje
 (2008, January)

PART.No

J1010SC100NN

